

90-DAY LIMITED WARRANTY

(This product warranty is valid in the United States and Canada only)

Radica China Limited warrants this product for a period of 90 days from the original purchase date under normal use against defective workmanship and materials (batteries excluded). This warranty does not cover damage resulting from accident, unreasonable use, negligence, improper service or other causes not arising out of defects in material or workmanship. Radica China Limited will not be liable for any costs incurred due to loss of use of this product or other incidental or consequential costs, expenses or damages incurred by the purchaser. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you. This warranty gives you specific legal rights and you may also have other legal rights, which vary from state to state.

During this 90-day warranty period, the game will either be repaired or replaced (at our option) without charge to the purchaser when returned prepaid with proof of date of purchase to: **Radica USA, Ltd., 13628-A Beta Road, Dallas, Texas 75244, USA.** Please remove the batteries and wrap the unit carefully before shipping. Please include a brief description of the problem along with your return address and mail it postage prepaid.

Products returned *after* the 90-day period has expired will be repaired or replaced (at our option) for a service charge of US \$10.00. Payment must be made by check or money order. This extended service will only be available for one year from the date of purchase.

IMPORTANT: Before returning the unit for repair, test it with fresh alkaline batteries. Even new batteries may be defective or weak and low battery power is a frequent cause of unsatisfactory operation.

RADICA:

**RADICA:®
GAMESTER™**

**PRO RACER 2, DUAL FORCE VIBRATION AND
"THE UNFAIR ADVANTAGE" ARE
TRADEMARKS OF RADICA CHINA LTD.
© 2002 RADICA CHINA LTD.
PRODUCT SHAPE™
ALL RIGHTS RESERVED**

**PLAYSTATION IS A REGISTERED
TRADEMARK OF SONY COMPUTER
ENTERTAINMENT INC. (SCEI).**

**US PRODUCT
SUPPORT
1.800.803.9611
www.gamesterusa.com**

<http://www.replacementdocs.com>

GAMESTER.

**PRO
RACER 2™**
THE ONLY HAND-HELD WHEEL



INSTRUCTION MANUAL

MODEL RC72160us

For 1 player / Ages 8 and up

P/N 82369300 Rev.A

INTRODUCTION

Congratulations on choosing the Gamester Pro Racer 2, the only handheld wheel for your PS2 video game console.

CONTENTS

- 1 x Pro Racer 2
- 1 x Instruction Manual

IMPORTANT

- Before using this product, read the PS2 Instruction Manual for safety, health and other information.
- This product will only work with the Playstation 2 video game console.

PRODUCT FEATURES

- The only handheld wheel
- Full motion steering
- Easy to reach buttons and D-pad
- Analog, Digital, and NegCon modes



MODE SELECTION

- Pro Racer 2 automatically defaults to Analog mode when plugged into a PS2 system.
- Press Mode button once to switch to digital mode.
- Hold Mode button down till light flashes to switch to NegCon Mode (Note: Some games do not support NegCon).

TROUBLE SHOOTING

Your Pro Racer 2 is not working:

- Make sure Pro Racer 2 is firmly plugged into either controller port on you PS2.
- Reset the PS2 video game console.

MAINTENANCE

- Handle this product carefully.
- Store this product away from dusty or dirty areas.
- Keep this product away from moisture or extreme temperature.
- Do not disassemble this product. If problems persist, consult the Warranty information located at the end of this Instruction Manual.

Please retain this for future reference.