



SUPERMAP
LEVEL II ROM DOCUMENTATION

by

FULLER SOFTWARE

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means electronic, mechanical, or photocopying, recording, or otherwise without written permission from the author. Printed in the United States of America.

Fuller Software is in no way attempting to infringe upon the proprietary rights of MICROSOFT by this publication. The expressed purpose of SUPERMAP is to aid users of LEVEL II microcomputers in using and understanding their machines.

IMPORTANT NOTICE

Fuller Software assumes no liability with respect to the use of this publication nor any damages resulting from the use of any information contained herein. SUPERMAP is sold in an "as is" condition and is not represented as being error free.

FULLER SOFTWARE
630 E. Springdale
Grand Prairie, TX 75051

SUPERMAP

by

ROGER FULLER

```
0000 POWER ON ROUTINE  TURN OFF CLOCK  ZERO A  THEN JUMP
*****

0008 RST  8H:  (HL)-((SP))  SN ERROR IF NON ZERO
*****

0010 RST 10H:  INCREMENT HL, PASS TROUGH STRING IGNORE CR AND SPACES.
              SET C IF NEXT CHARACTER NUMERIC.  RESET C IF NOT.
*****

0013 KEYBOARD ROUTINE (SEE 002B)
*****

0018 RST 18H:  HL-DE  Z SET IF EQUAL.  C SET IF DE>HL.
*****

001B DISPLAY ROUTINE
*****

0020 RST 20:  IF NTF=8  C IS RESET ELSE C SET.  A=NTF-3  S AND Z
              FLAGS VALID.  MAINTAINS BC, DE, HL.
*****

0028 RST 28H  BREAK VECTOR
*****

002B SCAN KEYBOARD RETURN WITH CHAR IN A  USES AF, DE
*****

0033 DISPLAY BYTE IN A ON SCREEN
*****

003B PRINTER DRIVER ENTRY
0049 SCAN KEYS WAIT FOR KEY PRESSED  USES AF, DE
*****
```

NOTE: SUPERMAP is designed to be transferred to a disassembled listing of LEVEL II BASIC. Three and five digit numbers are decimals.

KEYBOARD LOOKUP TABLE

0050 (ENTER)
0051 (ENTER) SHIFT
0052 (CLEAR)
0053 (CLEAR) SHIFT
0054 (BREAK)
0055 (BREAK) SHIFT
0056 (UP ARROW)
0057 (UP ARROW) SHIFT
0058 (DOWN ARROW)
0059 (DOWN ARROW) SHIFT
005A (LEFT ARROW)
005B (LEFT ARROW) SHIFT
005C (RIGHT ARROW)
005D (RIGHT ARROW) SHIFT
005E (SPACE)
005F (SPACE) SHIFT

0060 DELAY LOOP BC IS COUNTER 14.65 MICROSECONDS EACH LOOP

0066 NMI RESET

0075 NON DOS INITIALIZATION AREA MOVE 18F7-191C TO 4080-40A6
008B 41E8 TO INPUT BUFFER ADDRESS POINTER (40A7)
0091 LOAD DUMMY JUMP VECTORS IN DOS COMMANDS JUMP ADDRESSES. JUMP
WILL BE TO L3 ERROR (012D) INSTEAD OF DOS. USED DURING LEVEL II
INTERPRETATION OF BASIC PROGRAM. COMMAND ENTRY POINTS.
009F PLACE RETURN COMMANDS IN DOS LINK AREA (THESE ARE USED BY LEVEL
II MACHINE ROUTINES)
00B2 'MEMORY SIZE' ROUTINE CLEAR SCREEN
00B5 POINT TO 'MEMORY SIZE' MESSAGE
00B8 DISPLAY IT
00BB WAIT FOR USER INPUT
00BE IF (BREAK) ASK AGAIN
00C0 LOCATE 1ST CHAR
00C1 IS IT ANYTHING
00C2 IF SO SKIP MEMORY SIZE ROUTINE
00C4 TEST FOR END OF ACTUAL MEMORY. USED WHEN (ENTER) IS GIVEN
TO MEMORY SIZE QUESTION
00C7 HL=MEMORY POINTER
00CC GET A BYTE IN MEMORY
00CD SAVE IT IN B FOR LATER
00CE COMPLEMENT IT
00CF PUT IT BACK WHERE YOU GOT IT
00D0 SEE IF MEMORY WAS THERE TO RECEIVE IT
00D1 PUT BACK ORIGINAL BYTE
00D2 DO TIL MEMORY FAILS TEST
"*****"


```

0429 TEST FOR LAST ROW
042B JUMP IF LAST ROW
042D READJUST TO ROWS 4, 5 A=ROW * 8 + COLUMN# + 016
042F CHECK FOR = OR ) OR ?
0431 JUMP IF NOT
0433 ADJUST ASCII
0435 GET SHIFT BIT
0437 JUMP IF NOT SHIFT
0439 ADJUST ASCII
043B JUMP
"....."
043D A=(ROW * 8 + COLUMN # - 048) * 2
043E GET SHIFT BIT
0440 JUMP IF NOT
0442 A=COLUMN # * 2 + 1
0443 POINT TO CODE TABLE
0446 DISPLACEMENT
0449 COMPUTE POSITION IN TABLE
044A GET ASCII CODE
044B SAVE CHARACTER
044C LOAD DELAY COUNT
044F DELAY
0452 RETREIVE CHARACTER
0453 CHECK FOR (BREAK)
0455 LEAVE WITH CHAR
0457 RETURN

```

SYSTEM TAPE FORMAT

```

LEADER          256 zeros followed by a A5 sync byte

55              System format header byte
XX XX XX XX XX XX  6 char file name

3C              Data header
XX              Data length 00=256 bytes
LSB             Loading
MSB             Address
XX ... XX      Line itself
XX             Checksum of line bytes and load address

.
:
.

78              End of file marker
LSB             Entry
MSB             Address

```



```

0977* ABS: ARITH=ABS(ARITH). INTEGER OR SINGLE IN AND OUT.
      NTF REQUIRED AND MAINTAINED.
0982 ARITH= -ARITH: SINGLE ONLY. MAINTAINS BC, DE
      """"""""""
098A* SGN ACCEPT FLOATING POINT OR INTEGER. OUTPUT INTEGER IN ARITH
      """"""""""
0994 CHECK SIGN OF ARITH, FLOAT OR INTEGER. REQUIPES NTF. A=00 IF
      ARITH=0. A=01 IF ARITH GREATER THAN 0. A=FF IF ARITH LESS
      THAN 0. S AND Z FLAGS ALSO VALID
      """"""""""
09A4 LOAD SINGLE ARITH TO STACK. TO RETRIEVE POP BC, POP DE.
      A,BC,HL UNALTERED.
09B1 LOAD SINGLE: ARITH=(HL)(HL+1)(HL+2)(HL+3)
09B4 LOAD SINGLE: ARITH=BCDE. HL UNALTERED
09BF LOAD SINGLE: BCDE=ARITH.
09C2 LOAD SINGLE: BCDE=(HL)(HL+1)(HL+2)(HL+3)
09CB MOVE FROM (ARITH) TO (HL) 4 BYTES
09CE MOVE FROM (DE) TO (HL) 4 BYTES
      """"""""""
09D2 MOVE FROM (HL) TO (DE) NTF BYTES
09D3 MOVE FROM (DE) TO (HL) NTF BYTES
09D6 MOVE FROM (DE) TO (HL) A BYTES
09D7 MOVE FROM (DE) TO (HL) B BYTES

```

```

0A0C SINGLE COMPARE: ARITH-BCDE
      """"""""""
0A39 INTEGER COMPARE: HL-DE
      """"""""""
0A4F DOUBLE COMPARE: ARITH-ARITHEX
0A78 DOUBLE COMPARE: ARITHEX-ARITH

```

EDITOR ASSEMBLER SOURCE TAPE FORMAT

```

LEADER           256 zeros followed by an A5 sync byte

D3              Source header
XX XX XX XX XX XX File name

#1 #2 #3 #4 #5 Line # in ASCII (bit 7 is set)
20             Data header
XX ..... XX   Line (128 bytes maximum)
0D            End of line marker

.
.
.

1A             End of file marker

```

```

0A7F* CINT
0A83 ALREADY INTEGER
0A84 TM ERROR IF STRING
0A87 IF DOUBLE CONVERT TO SINGLE

*****

0A9A RETURN TO BASIC WITH OUTPUT OF USER ROUTINE IN HL.
0A9D FLAG IT INTEGER

*****

0AB1* CSNG
"*****"
0ACC INTEGER ARITH TO SINGLE ARITH CONVERSION
0ACF INTEGER HL TO SINGLE ARITH CONVERSION

*****

0ADB* CDBL: ARITH(DOUBLE)=ARITH(INTEGER OR SINGLE). REQUIRES NTF

*****

0AF4 TEST NTF=3 (STRING). IF STRING RETURN ELSE ERROR.
BC,DE,HL UNALTERED.
"*****"
0AF6 TM ERROR ENTRY POINT

*****

0B26* FIX: IF FLOATING POINT TRUNCATE TO INTEGER AND RETURN FLOATING
POINT. IF INTEGER RETURN. IF STRING ERROR.
"*****"
0B37* INT
0B38 IF INTEGER
0B39 IF DOUBLE
0B3B TM ERROR IF STRING

*****

```

```

0C70 DBL PRECISION SUBTRACTION: ARITH=ARITH-ARITHEX
0C77 DBL PRECISION ADDITION : ARITH=ARITH+ARITHEX
      " " " " " " " " " " " " " " " " " " " " " " " " " " " " " " "
0DA1 DBL PRECISION MULTIPLICATION: ARITH=ARITH*ARITHEX
0DE5 DBL PRECISION DIVISION : ARITH=ARITH/ARITHEX
0E65 LOAD DOUBLE PRECISION ASCII CONSTANT TO ARITH. POINT HL TO INPUT
      STRING DELIMITED BY 0 OR COMMA. AFTER LOAD HL POINTS TO
      DELIMITER
0E6C LOAD ASCII CONSTANT TO ARITH. RETURN THE LEAST NECESSARY NUMBER
      TYPE (SEE LEVEL II MANUAL FOR RULES) POINT HL TO INPUT STRING
      DELIMITED BY 0 OR COMMA

0E7B IF -
0E80 IF +
0E84 IF NUMERIC
0E89 IF .
0E8E IF E
0E92 IF %
0E97 IF #
0E9C IF !

```

```

0F40 MULTIPLY HL BY TEN

```

```

0FAB OUTPUT 'IN ' MESSAGE
      " " " " " " " " " " " " " " " " " " " " " " " " " " " " " " "

```

```

0FAF OUTPUT A LINE #

```

```

0FBD ARITH AND NTF TO ASCII CONVERSION HL POINTS TO STRING

```

```

13E7* SQR
1439* EXP

```

```

14C9* RND

```

```

1541* COS
1547* SIN
15A8* TAN
      " " " " " " " " " " " " " " " " " " " " " " " " " " " " " " "

```

```

15BD* ATN

```

1608 TABLE OF ENTRY POINTS FOR LEVEL II BASIC COMMANDS

1650 RESERVED WORD LIST FOR LEVEL II COMMANDS

ABS	D9 0977	GOSUB	91 1EB1	READ	8B 21EF
AND	D2 25FD	GOTO	8D 1EC2	REM	93 1F07
ASC	F6 2A0F	LF	8F 2039	RESET	82 0138
ATN	E4 15BD	INKEY\$	C9 019D	RESTORE	90 1D91
AUTO	B7 2008	INP	DB 2AEF	RESUME	9F 1FAF
CDBL	F1 0ADB	INPUT	89 219A	RETURN	92 1EDE
CHR\$	F7 2A1F	INSTR	C5 419D	RIGHT\$	F9 2A91
CINT	EF 0A7F	INT	D8 0B37	RND	DE 14C9
CLEAR	B8 1E7A	KILL	AA 4191	RSET	AC 419A
CLOAD	B9 2C1F	LEFT\$	F8 2A61	RUN	8E 1EA3
CLOSE	A6 4185	LEN	F3 2A03	SAVE	AD 41A0
CLS	84 01C9	LET	8C 1F21	SET	83 0135
CMD	85 4173	LINE	9C 41A3	SGN	07 098A
CONT	B3 1DE4	LIST	B4 2B2E	SIN	E2 1547
COS	E1 1541	LLIST	B5 2B29	SQR	CD 13E7
CSAVE	BA 2BF5	LOAD	A7 4188	STEP	CC 2B01
CSNG	F0 0AB1	LOC	EA 4164	STOP	94 1DA9
CVD	E8 415E	LOF	EB 4167	STR\$	F4 2836
CVI	E6 4152	LOG	DF 0809	STRING\$	C4 2A2F
CVS	E7 4158	LPRINT	AF 2067	SYSTEM	AE 02B2
DATA	88 1F05	LSET	AB 4197	TAB(BC 2137
DEF	BD 415B	MEM	C8 27C9	TAN	E3 15A8
DEFDBL	9B 1E09	MERGE	A8 418B	THEN	CA ----
DEFINT	99 1E03	MID\$	FA 2A9A	TIME\$	C7 4176
DEFSNG	9A 1E06	MKD\$	EE 4170	TO	BD ----
DEFSTR	98 1E00	MKI\$	EC 416A	TROFF	97 1DF8
DELETE	B6 2BC6	MKS\$	ED 416D	TRON	96 1DF8
DIM	8A 2608	NAME	A9 418E	USING	BF 2CBD
EDIT	9D 2E60	NEW	BB 1B49	USR	C1 27FE
ELSE	95 1F07	NEXT	87 22B6	VAL	FF 2AC5
END	80 1DAE	NOT	CB 25C4	VARPTR	C0 24EB
EOF	E9 4161	ON	A1 1F6C	+	CD 249F
ERL	C2 24DD	OPEN	A2 4179	-	CE 2532
ERR	C3 24CF	OR	D3 25F7	*	CF ----
ERROR	9E 1FF4	OUT	A0 2AFB	/	D0 ----
EXP	E0 1439	PEEK	E5 2CAA	↑	D1 ----
FIELD	A3 417C	POINT	C6 0132	>	D4 ----
FIX	F2 0B26	POKE	B1 2CB1	=	D5 ----
FN	BE 4155	POS	DC 27F5	<	D6 ----
FOR	81 1CA1	PRINT	B2 206F	&	26 4194
FRE	DA 27D4	PUT	A5 4182	'	3A 93 FB
GET	A4 4174	RANDOM	86 01D3		

1821 END OF TABLE MARKER

1822 TABLE OF JUMP ADDRESSES FOR ENTRY POINTS OF BASIC INSTRUCTIONS.

```

191D 'ERROR', 'IN', 'READY', 'BREAK' STRINGS FOR BASIC MESSAGES
1955 IQ TESTING SERVICE
1930 IF (409A)=2 SN ERROR OUTPUT GOTO EDIT MODE
197A OM ERROR ENTRY POINT
      "*****"
199A /O ERROR ENTRY POINT
199D NF ERROR ENTRY POINT
19A0 RW ERROR ENTRY POINT
19A2 ERROR OUTPUT ROUTINE. ERROR CODE IN E
19E6 RETURN TO BEGINNING OF LINE. ZERO A
19E9 POINT HL TO BOTTOM OF ERROR MESSAGE TABLE
19EF NON DOS RET
19EF ZERO D
19F0 GET A '?'
19F2 DISPLAY IT
19F5 ADD ERROR CODE DISPLACEMENT TO POINTER
19F6 GET ERROR MESSAGE
19F7 DISPLAY 1ST CHAR
19FA NUMERIC CHECK
19FB DISPLAY 2ND CHAR
19FE POINT TO 'ERROR'
1A06 DISPLAY IT
1A0D IF DE=(40EA)
1A0E THEN POWER UP RESET
1A14 DISPLAY ' IN ' LINE #
1A17 LOAD A TAB(1)
1A19 RETURN TO BASIC COMMAND MODE ( 'READY' ROUTINE) PRINT A
1A1C RETURN IF NON DOS
1A1F TURN OFF CASSETTE
1A22 RETURN TO BEGINNING OF LINE OR CR. ZERO A
1A25 POINT TO 'READY' MESSAGE
1A28 OUTPUT IT
1A2B GET ERROR CODE
1A2E TEST FOR SN ERROR
1A30 CALL IF SN ERROR
1A33 RETURN ADDRESS
1A39 GET AUTO FLAG ( AUTO=NON ZERO)
1A3D JUMP FOR NON AUTO
      "*****"
1A3F GET CURRENT LINE #
1A43 OUTPUT LINE #
1A48 SEE IF LINE # OCCUPIED (CARRY SET) READY TO DISPLAY IF MAT
1A4B GET A ASTERISK
1A4D PRINT A SPACE OR AN ASTERISK
1A4F GET A SPACE OTHERWISE
1A51 DISPLAY CORRECT CHARACTER
1A54 INPUT INTO BUFFER
1A58 (BREAK) SETS CARRY
      "*****"

```

```

1A5A  TURN OFF AUTO AND JUMP BACK
      "*****"
1A60  GET LINE INCREMENT
1A63  ADD TO CURRENT LINE #
1A69  (BREAK) IF OVERSIZE LINE # RESULTS
1A6C  (BREAK) IF LINE # > 65529X
      "*****"

1A76  GET PROMPT
1A78  DISPLAY IT
1A7B  INPUT INTO BUFFER
1A7E  JUMP BACK IF BREAK
1A81  FIND FIRST CHARACTER
1A84  JUMP BACK IF NULL
1A88  CHECK FOR NUMERIC THEN SCAN PAST LINE # (LINE # IS IN DE)
1A8B  SCAN
1A99  ENCODE INPUT INTO LEVEL II TOKENS
1A9D  FLAGS DECIDE IF COMMAND MODE
1A9E  ENCODED STATEMENT POINTER
1AA1  NON DOS RET
1AA4  IF COMMAND MODE?
1AA7  SAVE LINE #
1AA8  SAVE LINE LENGTH
1AA9  ZERO
1AAA  RESET RESUME + RETURN FLAG
1AAD  SCAN 1ST TOKEN
1AB1  SAVE LINE #
1ABF  SAVE THE LINE #
1AB5  SEARCH FOR A MATCHING LINE #  C=NONE  Z=FOUND
1AB9  IF NONE MAKE ROOM
1ABF  JUMP FOR MATCH
1AC6  LINE LENGTH
1AC7  HL= NEW END OF BASIC PROGRAM
1AC9  MAKE SURE BRAIN WON'T OVERFLOW
1ACD  STORE END OF BASIC PROGRAM POINTER
1AD0  HL=LINE TO BE MOVED
1AD3  HL=LINE # POINTER
1AD6  DE=LINE #
1AD9  HL=LINE POINTER (TEXT)
1AE1  MOVE NEW LINE INTO PLACE
1AE6  LOOP TIL LINE IS MOVED
1AE9  FIX LINE POINTERS
1AEC  NON DOS RETURN
1AEF  HERE'S WHY EDITING A PROGRAM DESTROYS VARIABLES, ETC.
1AF2  NON DOS RETURN
1AF5  BACK TO THE FARM

```

The LEVEL II ROM does not use the alternate registers.

1AFC FIX THE LINE POINTERS ROUTINE
1B01 RETURN IF END OF OF BASIC
1B02 MOVE
1B03 PAST
1B04 THE NEXT LINE POINTER AND LINE #
1B06 CHECK FOR END OF LINE
1B08 DON'T QUIT TIL YOU SUCCEED
1B0A GET THE JOB DONE
1B0E RERUN ROADRUNNER CARTOON

1B2C SEARCH FOR MATCHING LINE # IN BASIC. DE=DESIRED LINE #. GET
FIRST LINE FROM (40A4)
1B2F SAVE POINTER IN BC
1B31 CHECK FOR END OF BASIC PROGRAM (STAY OUT OF JUNKYARDS)
1B35 RETURN IF END
1B36 POINT TO CURRENT LINE #
1B3B HL=CURRENT LINE #
1B3C MATCH? Z=YES C=HL<DE
1B3D NEXT LINE POINTER TO HL
1B44 RETURN IF MATCH FOUND (CARRY SET)
1B46 RETURN (NO SUCH LINE)
1B47 TRY NEXT LINE #

1B49* NEW
1B4A CLEAR SCREEN
1B4D START OF BASIC PROGRAM
1B50 TROFF
1B53 TURN OFF AUTO
1B56 ERASE PROGRAM BY MAKING ITS LEADERS ZILCH
1B5A RESET END OF PROGRAM POINTER
1B64 26 VARIABLES ARE
1B6C SET TO SINGLE PRECISION HERE
1B6F RESET RESUME FLAG
1B74 RESET ON ERROR STORAGE
1B77 RESET CONT LOCATION
1B7A GET END OF MEMORY
1B7D
1B88 RESTORE DATA POINTER
1B83 GET END OF BASIC LOCATION
1B86 RESET VARIABLES POINTER
1B89 RESET ARRAYS POINTER
1B90 GET START OF STRING SPACE POINTER
1B95 SET STACK POINTER TO START OF STRING SPACE - 2
1B9A SP=STRING SPACE POINTER
1BA1 SELECT VIDEO FINISH PRINTING
1BA4 TURN OFF CASSETTE

1BB3 PRINT '?' AND INPUT FROM KEYBOARD GO ON CR

```

1CA1* FOR
1CFB CHECK FOR 'STEP ' TOKEN
1CFD DEFAULT VALUE OF 1
1CFE IF NOT 'STEP '
1D4A '(LINE NUMBER)' TRON USAGE
      "*****"

1D5A BASIC INTERPETER
1D60 REMOVE BIAS
1D62 CHECK FOR A TOKEN
1D62 JUMP IF NOT
1D6A DOUBLE REMAINDER (REQUIRED FOR 2 BYTE ADDRESSES)
1D6B SAVE OFFSET
1D6C IN B
1D6F POINT TO VECTORS
1D72 LOCATE DESIRED ROUTINE ADDRESS
1D73 LOW BYTE TO C
1D75 HIGH BYTE TO B
1D76 SAVE ON STACK
      "*****"

1D78 RST 16

```

```

1D91* RESTORE
1D92 GET BEGINNING OF PROGRAM
1D96 RESTORE DATA POINTER

```

```

1D9B DISPLAY LINE NUMBER

```

```

1DA0 CHECK FOR PAUSE
1DA2 WAIT FOR KEYSTROKE TO RESUME
1DA5 SAVE IT
1DA8 01= BREAK
1DA9* STOP
1DD4 SELECT VIDEO
1DD7 RETURN TO BEGINNING OF LINE

```

```

1DAE* END

```

1DE4* CONT
1DEB OUTPUT CN ERROR IF (40F7)=0

1DF7* TRON AF=TRON
1DF8* TROFF

1E00* DEFSTR
1E03* DEFINI
1E06* DEFSNG
1E09* DEFDBL
1E0B CHECK FOR SYNTAX (LETTER NEEDED IN DEF---)
1E0E GET ADDRESS OF SN ERROR
1E11 SAVE ON STACK FOR POSSIBLE USE
1E12 SN ERROR IF NO LETTER
1E13 CONVERT ASCII LETTER TO DISPLACEMENT INTO TABLE OF 26 LETTERS
1E15 SAVE DISPLACEMENT IN C
1E16 SAVE DISPLACEMENT IN B
1E17 GET NEXT CHAR
1E18 IS IT -
1E1A IF NOT DON'T USE A RANGE
1E1D CHECK FOR LETTER
1E20 SN ERROR IF NOT
1E21 GET DISPLACEMENT
1E23 PUT IN B
1E24 GET TO NEXT CHAR
1E25 LOAD ENDING POINT
1E26 SUBTRACT BEGINNING POINT
1E27 SN ERROR IF VARIABLES REVERSED
1E28 BUMP COUNT (IN CASE VARIABLES SAME)
1E29 SAVE NEXT CHAR POINTER AND CLEAR SN ERROR VECTOR
1E2A LOAD START OF VARIABLE DEFINITION AREA
1E2D ZERO B
1E2F DETERMINE ENDING POINT
1E30 SET VARIABLE TYPE FLAG
1E31 BUMP TABLE POINTER
1E32 REDUCE COUNT
1E33 LOOP TIL COUNT ZERO
1E35 RETURN NEXT CHAR POINTER
1E36 GET NEXT CHAR
1E37 IS IT A COMMA
1E39 IF NOT
1E3A GET NEXT VARIABLE
1E3B DEF--- AGAIN
1E3D CHECK FOR LETTER IN (HL). SET C IF NOT ELSE RESET

```

1E4F  GET CHAR
1E50  IS IT A PERIOD
1E53  GET PERIOD ADDRESS
1E57  JUMP IF PERIOD
1E5A  FOR RST 10
1E5B  INITIALIZE DE      DE=LINE # ON EXIT
1E5E  LOCATE 1ST CHAR AND NUMERIC CHECK
1E5F  RETURN IF NON NUMERIC
1E60  SAVE LOCATION
1E61  SAVE ASCII NUMERIC DIGIT
1E62  OVERSIZE LIMIT (65520)
1E65  PRE-FLIGHT
1E66  SN ERROR IF DE > 1998
1E69  HL=DE
1E6B  HL=(HL + DE)
1E6C  HL=(HL + DE) + (HL + DE)
1E6D  HL=(HL + DE + HL + DE) + DE
1E6E  HL=(HL+DE+HL+DE+DE) + (HL+DE+HL+DE+DE)=4*HL + 6*DE=010*DE
1E6F  RETREIVE ASCII NUMERIC DIGIT
1E70  CONVERT ASCII CODE TO #
1E72  SAVE # IN E
1E73  ZERO D SO DE=#
1E75  ADD # TO SUBTOTAL (HL)
1E76  DE=010*DE + #
1E77  RESTORE POINTER

```

```

1E7A* CLEAR
1E7D  COMPUTE THE AMOUNT AS AN INTEGER
1E84  END OF MEM POINTER
1E8D  OM ERROR IF HL<DE
1E9C  LOAD STRING POINTER

```

```

1EA3* RUN

```

```

1EB1* GOSUB

```

```

1EC2* GOTO      EVALUATE LINE #
1ED9  UL ERROR ENTRY POINT

```

1EDE* RETURN
1EEC RG ERROR ENTRY POINT
1F05* DATA
1F07* REM
* ELSE

1F21* LET

1F6C* ON
1F70* ON ERROR
1F80 IF UL ERROR
1F89 GET ERROR FLAG
1F8E GET ERROR CODE
1F91 LOAD INTO E FOR ERROR ROUTINE
1F92 JUMP

1FAF* RESUME POINT TO ERROR FLAG
1FB3 CHECK IT
1FB4 RW ERROR IF ZERO

1FF4* ERROR
2003 UE ERROR ENTRY POINT

2008* AUTO
200B SAVE DEFAULT VALVE OF 10
2019 SAVE LINE # INCREMENT
2022 IF SN ERROR
2025 CHECK FOR ZERO INCREMENT
2028 FC ERROR IF Z
202B SAVE INCREMENT
202E SET AUTO FLAG
2036 BACK TO THE FARM

2039* IF
2044 IF THEN
2060 IF NOT ELSE

```

2067* LPRINT      SELECT LPRINTER FOR OUTPUT
207B  IF EXPRESSION ISN'T INTEGER
207F  POINT TO DISPLAY
2082  COMPUTE LOCATION
2083  SAVE IT
2089  UPDATE CURSOR
      *****

206F* PRINT
2076* PRINT @    EVALUATE EXPRESSION
2093* PRINT #    WRITE LEADER AND SYNC BYTE
20A5  IF PRINT USING
20AA  IF PRINT TAB(
20B0  IF COMMA
20B5  IF SEMI COLON
20BE  IF STRING
20FE  USED TO RETURN TO BEGINNING OF LINE AND ZERO A
2137* TAB(

```

```

2169  OUTPUT DEVICE T, V, P -1, 0, 1
      *****

216D  TURN OFF CASSETTE IF NEEDED
2171  SELECT VIDEO
      *****

2178  'REDO ' MESSAGE STRING

```

```

219A* INPUT
219D  REDO
21A9* INPUT #
21AD  250 BYTES LIMIT
21AF  POINT
21B2  READ A BYTE
21B5  INTO THE BUFFER
21B7  CR YET?
21BB  LOOP BACK
21BE  END OF FILE MARKER
21C0  TURN OFF TAPE
      *****

21EF* READ
      *****

227C  'EXTRA IGNORED ' STRING
      *****

22B6* NEXT

```

2836* STR\$
2866 QUOTE
2891 NTF = STRING
28A1 ST ERROR ENTRY POINT

28A7 OUTPUT A MESSAGE; POINT HL TO STARTING ADDRESS OF STRING; MARK
END WITH A 00 OR 22 OUTPUT DEVICE SELECTED BY (409C).
UPDATES LINE CURSOR POSITION

2A03* LEN

2A0F* ASC

2A1F* CHR\$

2A2F* STRING\$

2A61* LEFT\$

2A91* RIGHT\$

2A9A* MID\$

2AC5* VAL

2AEF* INP GET PORT ADDRESSES

2AF2 LOAD IT

2AF5 INPUT FROM CORRECT PORT

2AF8 RETURN VIA USR CODE

2AFB* OUT GET BYTE

2AFE OUTPUT IT

2B01* STEP

2B02 COMPUTE VALUE OF EXPRESSION

2B06 CONVERT IT TO INTEGER

2B0B MSB TO A

2B0C CHECK FOR OVERFLOW

2B0E GET PORT #

2B11 SET PORT # FOR INPUT

2B14 SET PORT # FOR OUTPUT

2B17 SYNTAX CHECK

2B1C COMPUTE VALUE

2B1F CONVERT TO INTEGER

2B22 FC ERROR IF OVERFLOW

Notes on the EDITOR ASSEMBLER

- 4113 Top of memory pointer
- 4115 Start of memory pointer
- 41C3 Start of symbol table pointer
- 4301 Keyboard driver entry address pointer
- 4309 Video driver address
- 4311 Lprinter driver address
- 45AA Lprinter driver (patch your printer here)
- 4905 Command table (have a feast)
- 4925 B command (go someplace new)

3000-37DD RESERVED THERE IS NOTHING HERE NO MEMORY AT ALL
 37DE DOS COMMUNICATION STATUS ADDRESS
 37DF DOS COMMUNICATION DATA ADDRESS
 37E0 INTERRUPT LATCH ADDRESS
 37E1 DISC DRIVE SELECT LATCH ADDRESS
 37E2 CASSETTE DRIVE LATCH ADDRESS
 37E8 LPRINTER PORT ADDRESS
 37EC FLOPPY DISC CONTROLLER ADDRESS

-----KEYBOARD MEMORY-----
 COL # = 0 1 2 3 4 5 6 7
 3801 ROW 0 @ A B C D E F G
 3802 ROW 1 H I J K L M N O
 3804 ROW 2 P Q R S T U V W
 3808 ROW 3 X Y Z
 3810 ROW 4 ! " # \$ % & ' 0 1 2 3 4 5 6 7
 3820 ROW 5 () * + < = > ? 8 9 : ; , - . /
 3840 ROW 6 ENT CLS BRK ↑ ↓ ← → SPS
 3880 ROW 7 SHIFT

3C00-3FFF VIDEO MEMORY

4000 RST 8
4003 RST 10
4006 RST 24
400C RST 32
400C RST 40
400F RST 48
4012 RST 56

-----KEYBOARD CONTROL BLOCK

4015 DEVICE TYPE
4016 DRIVER ADDRESS (INTERCEPT HERE FOR DEBOUNCE)
4018 0
4019 0
401A 0
401B 'K '
401C 'I '

-----VIDEO CONTROL BLOCK

401D DEVICE TYPE
401E DRIVER ADDRESS
4020 CURSOR POSITION IN MEMORY (2 BYTES)
4022 CURSOR CHARACTER
4023 'D '
4024 'O '

-----LPRINTER CONTROL BLOCK

4025 DEVICE TYPE
4026 DRIVER ADDRESS
4028 # LINES PER PAGE KEPT HERE
4029 CURRENT LINE # PRINTER IS ON
402A 0
402B 'P '
402C 'R '

4036-403C 7 BYTE WORK AREA FOR KEYBOARD ROUTINE

403D PRINT SIZE FLAG 0=64 CHAR 8=32 CHAR ALSO USED IN TAPE
OUTPUT TO PREVENT RESETTING SIZE DURING AN OUT 255

```

-----TIMES STORAGE AREA
4040 25 MS TICKS
4041 SECONDS
4042 MINUTES
4043 HOURS
4044 YEAR
4045 DAY
4046 MONTH
408E ENTRY POINTER TO USR ROUTINES
4093 INP ROUTINE
4094 PORT #
4096 OUT
4097 PORT #
4099 INKEY$ STORAGE
409A ERROR CODE STORAGE FOR RESUME USE
409B PRINTER CARRIAGE POSITION
409C DEVICE TYPE FLAG -1=TAPE 0=VIDEO 1=LPRINTER
409D PRINT# USE
40A0 START OF STRING SPACE POINTER
40A2 CURRENT LINE BEING PROCESSED
40A4 START OF BASIC PROGRAM POINTER
40A6 LINE CURSOR POS USED FOR TAB
40A7 INPUT BUFFER POINTER
40AA LSB OF SEED FOR RND
40AB LSB OF SEED FOR RND ALSO USED IN RANDOM
40AC MSB OF SEED FOR RND
40AF NTF (NUMBER TYPE FLAG) 2=INTEGER 3=STRING 4=SINGLE 8=DOUBLE
40B1 TOP OF BASIC MEMORY POINTER
40B3 STRING WORK AREA POINTER
40B5--STRING WORK AREA
40D6 MEMORY SIZE ERRATA 40D6 SHOULD BE NEXT STRING STORAGE POINTER
40DC DIM USE
40DE PRINT USING
40DF ENTRY POINT STORAGE FOR SYSTEM TAPES
40E1 AUTO FLAG 0=NOT AUTO ELSE AUTO
40E2 CURRENT LINE #
40E4 AUTO INCREMENT SIZE
40E6 ENCODED STATEMENT POINTER
40E8 S T A C K P O I N T E R POINTER
40EA USED DURING RESUME
40EC EDIT LINE #
40EE USED DURING RESUME
40F5 LAST LINE # EXECUTED
40F7 USED TO CONT
40F9 SIMPLE VARIABLES POINTER
40FB ARRAYS POINTER
40FD FREE SPACE
40FF DATA POINTER
-----VARIABLE TYPE DECLARATION TABLE
4101-411B 2=INTEGER 4=SINGLE 8=DOUBLE 3=STRING
411B TRON FLAG 0=TROFF

```

```

-----ARITH-----
      INTGER   SINGLE   DOUBLE
411D
411E
411F
4120
4121   LSB     LSB     LSB
4122   MSB     LSB     LSB
4123
4124

```

```

-----ARITHEX-----
4127   LSB     LSB     LSB
4128   MSB     LSB     LSB
4129   MSB     MSB     LSB
412A
412B
412C
412D
412E

```

```

-----
4130  LINE # WORK AREA POINTER

```

```

-----DOS ENTRY POINTS-----

```

```

4152  CVI
4155  FN
4158  CVS
415B  DEF
415E  CVD
4161  EOF
4164  LOC
4167  LOF
416A  MKI$
416D  MKS$
4170  MKD$
4173  CMD
4176  TIME$
4179  OPEN
417C  FIELD
417F  GET
4182  PUT
4185  CLOSE
4188  LOAD
418B  MERGE
418E  NAME
4191  KILL
4194  &
4197  LSET
419A  RSET
419D  INSTR
41A0  SAVE
41A3  LINE

```

```

-----INPUT BUFFER AREA-----

```

```

41E8-42E8  NOTE STACK POINTER IS 4288 FOR SYSTEM

```

```

-----
42E9  BASICALLY ONLY THE BEGINNING!

```